




360 Auto Rotate Tracking Mobile Phone holder user's manual




The gimbal can perform 360° rotation shooting without dead angle according to the face position




Open the phone holder and slide the phone into the phone holder according to the front direction of the phone lens to adjust the phone properly.




No need to adjust the angle when standing or sitting down, the gimbal automatically follows



Manually switch the phone's horizontal and vertical screen mode



The bottom of the gimbal is equipped with a 4 / 1 universal mount, which can be used with a tripod



4/1 universal interface

- **Key use**
Long press the switch button: the device is turned on/off.
Three-click the switch button: the face follow function is locked/opened
- **Indicator light display**
After the device is turned on, the green light is always on by default. The red light flashes when the device is lack of power, the red light is always on when the device is charging, and the red light is off when the device is full. full red light goes out.
- **Function Description**
After the device is turned on, the follow mode will be automatically turned on, please ensure that the face is in the viewable range of the camera. At this time, the device will be in the follow state, and the device will follow the position of the face to rotate.
- The gimbal follow effect may be affected by the shooting environment. Please choose a shooting environment with suitable light and keep a moderate distance from the gimbal (the best distance is 3-5m)
- If the moving speed of the tracking target is too fast, the target may be lost. In this situation, the gimbal will continue to rotate to find the tracking target. If you need to lock the face to follow, three-click switch button on the device locks the face to follow. If you need to enable the up and down follow function on the face, three-click the switch button to enable the follow function on the face. If you need to turn off face following, please turn off the device.
- **Tips**
 1. This product contains batteries, please do not place the product in a high temperature/high humidity environment to avoid accidents.
 2. Do not manually rotate the gimbal, so as not to damage the internal structure of the product and cause functional damage.
 3. It is recommended to fully charge the device for the first use, so as the device has a longer lifespan.

Product parameter

Name	360 Camera Live Auto Face Tracking Phone Holder-2 Axis
Model	XY49
Load	300g
Net weight	200g
Product Size	95*95*170mm
Support phone size	56-100mm
Mechanical angle	360° horizontal rotation
	25° vertical flip up
	20° vertical downward flip
Battery capacity	2000mAh lithium battery
Use time	5-10 hours