

# 1. IR Receiver 8. USB(Mouse, writing 2. Camera Lens pad, etc.) 3. LED Light 9. USB(PC&Flash drive) 4. Stepless Knob 10. LINE in 5. SD Card 11. LINE out 12. Power 6. HDMI in 7. HDMI out

2. Device and interface instruction

**■** Menu Record ★ LED Light on/off Snap

Switch video source ← Change the resolution/back

\* Freeze AF Confirm/auto focus Rotate Power on/off


### 3. Software download

- Windows
- Mac
- Chromebook
- Android

#### 4. Device connection

#### PC Connection

- 1. Plug in the power adapter to the power socket and Document Camera.
- 2. Connect the USB cable to the PC and Document Camera.
- 3. Install the software.




Windows XP and above \* Software download:

https://www.joyusing.com/download.html

★ Detailed Instructions: https://www.joyusing.com/download.html

#### PC-free

- 1. Plug in the power adapter to power socket and Document Camera.
- 2. Connect the HDMI cable to the Document Camera and Touch screen.



Document Camera and external equipment connections as below:

| Document<br>Camera Interface | Connection Cable | Display<br>Interface |
|------------------------------|------------------|----------------------|
| HDMI_OUT                     |                  | HDMI_IN              |
| HDMI_IN                      |                  | HDMI_OUT             |

## 5. Attention

## Before use:

- Do not leave it under direct sunlight or by heaters. It maybe discolored or damaged.
- Do not place this product in any humid, dusty, or vibrating locations.
- . Carry the product by holding the base in both hands. Never hold the product by the arm or the camera head.
- Use a soft, dry cloth for cleaning instead of any volatile solvent.
- When the device is not in use for a while, please turn off the power.
- Fold the arm when the product will not be used for a long time.

#### During use:

- Please prevent children from operating the device without supervision.
- Recommended environmental conditions: Temperature: 0°C 40°C (32°F - 104°F).
- Humidity: 30% 85%(No condensation).
- Use the product on a stable base, desk, or table.
- Do not turn or flip the camera head or arm to its limitation as below manual instructs
- Do not point the camera lens directly at the sunlight. It may be damaged and fails to image.
- Do not look directly to the LED lamps to prevent your eyes from being
- The product may not be operated properly if a USB hub is used to connect the product and a PC.
- Be careful to prevent the unit from dropping or overturning
- Please prevent the camera head to hit the desk top or any other hard objects, or it can be damaged easily.

## WiFi connection

- 1. Download from our website or QR code and install our APP.
- 2. Find the device in available WiFi list and input correct password.
- 3. Open software or APP to connect to the device.
- Windows
- Mac
- Chromebook
- Android

